

GB ELECTRIC MINI OVEN USER'S MANUAL

RO MANUAL DE UTILIZARE CUPTOR ELECTRIC
MEDIU

GB ELECTRIC MINI OVEN USER'S MANUAL.....5

RO MANUAL DE UTILIZARE CUPTOR ELECTRIC
MEDIU.....16

Dear customer,

Thank you for relying on products. We aim to allow you to optimally and efficiently use this environment-friendly product produced in our modern facilities under precise conditions with respect to sense of quality in total.

We advise you to read these operating manual thoroughly before using the mini oven and keep it permanently so that the features of the mini oven you have purchased will stay the same as the first day for a long time and serve in an optimum efficient way.

NOTE:

This Operating Manual is prepared for multiple models. Your appliance may not feature some functions specified in the manual.

The product images are schematic.

This product has been produced in modern environment-friendly facilities without adversely affecting nature.

"Complies with AEE Regulation."

Warnings.....	5
Electrical Connection and Safety	8
Explanation of the Oven and the Control Panel Technical Specifications	9
Cooking Chart	10
Operation of the Oven.....	10
If Your Oven is not Working.....	11
Oven lamp	11
Maintenance and Cleaning.....	11
Yogurt fermentation and the use of steam cleaning.....	12
Function Digital clock usage (*)......	13
Compliance with AEEE regulations and Waste Disposal	15
Package Information.....	15

(*) option

WARNINGS

This appliance is manufactured in accordance with the safety regulations. Operation against the rules cause harm both to the person and the appliance.

Do not put any flammable, ignitable materials or material that may melt or deform due to the heat inside the oven against possible risks even when your appliance is not operated.

The appliance is not intended to be operated by means of an external timer or separate remote-control system

Door surface may reach high temperatures when the appliance is operated.

Do not pour cold water to the tray or inside the oven while the surface of the appliance is still hot. Surface of the appliance may get damaged as a result of the sudden change in the temperature, and it may cause scaldings.

Long term intense use of the appliance may require extra ventilation, for example, opening a window, or a better ventilation, such as increasing the mechanical ventilation level. Put curtains, tulle, paper or any flammable (ignitable) material away from the appliance before starting to use the appliance. Do not put ignitable or flammable materials on or in the appliance.

Keep an eye on the children in the vicinity of the appliance.

This appliance is not intended to be used by people with physical, sensory and mental disabilities (including children) or those who have not adequate experience and knowledge regarding its use, unless they are under the supervision of a person responsible for the safety of the appliance.

Appliance may be used by children above age of 8, persons with limited physical, perceptual or mental abilities or persons with a lack of experience and knowledge if they are supervised or given instructions on the operation of the appliance and any relevant risks they may be encountered.

Children should not tamper with the appliance.

Cleaning and user maintenance of the appliance shall not be performed by unattended children.

Appliance shall be very hot while it is being operated or after a short while when it is operated; do not touch heater surfaces, and let children to touch these surfaces.

Keep the appliance and cord away from children under 8. Children shall be supervised to ensure that they do not play with the appliance.

This appliance is intended to be used in household and similar applications such as:

- Staff kitchen areas in shops, offices and other working environments;
- Farm houses;
- By clients in hotels, motels and other residential type environments;
- Bed and breakfast type environments.

Do not apply pressure on the oven door with heavy objects when the door is open; do not lean, place heavy objects on the door or handle the appliance by holding its door.

Use your appliance for cooking and heating your meal only. Do not use your appliance for unintended purposes (heating the room, for commercial purposes etc.).

Ensure that the appliance is unplugged before replacing the lamp of your appliance to prevent a risk of electric shock.

CAUTION!

The surfaces of the areas with this label are hot.
Do not touch.



ELECTRICAL CONNECTION AND SAFETY

Your appliance requires a current of 13 Amperes. Have the appliance installed by qualified persons, if required.


Your appliance is designed for a power supply of 220-240V, ~ 50/60Hz. If your mains supply specifications are different from the specified values, contact qualified persons.

Electrical connection of your appliance shall only be performed with earthed outlets installed as per the regulations. Contact authorized service if an earthed outlet is not available where the appliance shall be placed. Manufacturer is not responsible for damages caused by unearthed outlets.

If the mains cord (plugged cord is damaged, this cord must be replaced by the importer or its service agent or an equally qualified personnel to prevent a hazardous situation.

Power cord of your appliance shall not come into contact with the hot components of the appliance.

EXPLANATION OF THE OVEN AND THE CONTROL PANEL



1- Control panel

2- Oven body

3- Handle

4- Cooker

5- Heaters

6- Oven pedestals


7- Oven glass door

8- Control buttons

9- Circular tray (Option)

10- Rectangular tray

11- Wire grill




Timer




Top heater


Bottom heater


Bottom and top heater

Bottom heater and Turbo Fan


Bottom and Top heater
and Turbo fan




Thermostat




Programmer

Timer: Set the timer to the recommended cooking time at the desired thermostat degree. When the set time has expired, timer shall cut off the power of the heaters and provide a warning with a tingling sound. Set the timer, programmer and thermostat buttons to zero position to turn off your device. When the timer is set to  position, it will be working independent of the time.

Thermostat: Thermostat ensures a temperature from 40 to 240 °C inside the oven.

TECHNICAL SPECIFICATIONS

Features	MINI OVEN 45 LT
External width	590 mm
External depth	470 mm
External height	330 mm
Internal width	440 mm
Internal depth	420 mm
Internal height	240 mm
Thermostat	40 to 240°C
Timer (*)	0 to 90 min.
Bottom heater	800 W
Top heater	600 W
Supply voltage	220-240V. ~ 50/60Hz.
Turbo fan (*)	13 - 15 W
Oven lamp (*)	15 W

(*): This feature is only available on some models.

COOKING CHART

Below you may find the information about the food we have tested in our laboratories to determine their cooking times. Cooking times may vary as per mains voltage, quality, amount of the ingredients to be cooked, and the temperature. Meals you cook using these values may not appeal to your tastes. You may discover different values by making experiments to achieve different flavours and results that appeal to your taste.

Food	Thermostat setting (°C)	Cooking time (min.)	Shelf order
Cookie	170-180	25-30	Center shelf
Cake	170-190	30-40	Center shelf
Pie	180-220	40-50	Center shelf
Muffin	160-180	30-40	Center shelf
Pasta (baked)	190-210	20-30	Center shelf
Fish	220-MAX	30-40	Center shelf
Lamb	220-MAX	90-120	Center shelf
Mutton	220-MAX	90-120	Center shelf
Veal	220-MAX	90-120	Center shelf
Turkey	220-MAX	45-55	Center shelf
Poultry	220-MAX	75-100	Center shelf
Defrost	60-120	55-60	Center shelf

"Pre-heat your oven before cooking.

You may consider the time required until the temperature light is turned off for the first time as the pre-heating time."

OPERATION OF THE OVEN

Connect the plug to the earthed outlet. Bring the timer to manual or automatic cooking position. Set the thermostat to a proper temperature as per the values in the cooking chart. If you have set the timer to manual, you shall hear a warning sound at the end of cooking.

Some smoke and odour may occur while the protective materials on the heaters harden during the first operation of your oven. This is normal and not a manufacturing fault.

In order to make yoghurt: Boil the unpasteurised milk. Cure the boiled milk after it is cooled. Set the oven temperature to 40 - 50 °C, and operate the fan. Cook the cured milk in the oven for 3 to 3.5 hours in a pan with a lid.

Thawing: Remove the food to be thawed from its container and place it on the grill. Slide the rectangular tray under the grill to collect dripping water. Thus, thawed food shall not be kept inside its thawed water. Do not use thawed water (for health purposes) and discharge it.

You may use thawing feature as specified in the cooking chart,

It is recommended that you use top and bottom heaters and the turbo fan (☰) while thawing. As the thawing times vary as per the weight of the food, check it once in a while.

Do not cook using the rectangular and circular trays at the same time in the oven.

We recommend you to pre-heat your oven 8 to 10 minutes before cooking.

This oven is intended for household cooking only. Do not use for other purposes.

IF YOUR OVEN DOES NOT OPERATE

Please check if the power cord is plugged to the outlet securely. Check the mains supply.

Check the fuse.

Check for any damage to the power cord. Contact the authorized dealership if the issue is not resolved.

OVEN LAMP (*)



WARNING: To avoid electric shock, ensure that the device circuit is open before changing the lamp. (Open circuit means that the power is cut-off.)

Cut off the power supply of your appliance first, and ensure that the it is cooled down.

Remove the glass protector by rotating as shown in the figure.



Then, remove the lamp by rotating it, and install the new lamp with the same specifications. Lamp specifications shall be as follows:

220-240 V , 50/60Hz.

15 W

Type E14

Finally, install the glass protector to its original position.

MAINTENANCE AND CLEANING



Unplug your appliance.

Appliance may be very hot while it is being operated or after a short while when it is operated.


In this case, do not touch hot parts.


Do not clean the interior parts, door, tray and other parts of the oven with tools such as bristle brushes, steel wool or knives. Do not use abrasive and scratching detergents.

CURING YOGHURT

Select  yoghurt mode from thermostat section while the oven is empty, set the switch  to lower resistance, pre-heat for 10 minutes and start curing at somewhere else.

For curing, we boil the raw milk we have purchased at 90°C for minutes, and then cool it down to 43-45°C (curing temperature). Add yeast with a ratio of 1%-3% add stir slowly while the milk is at this temperature. Put the milk added with yeast to the 1st shelf of the pre-


heated oven without closing its lid and close the oven door  and set the timer to manual. After 5 hours, remove the cured yoghurt from the oven and keep it at room temperature for 15-20 minutes, and keep the yoghurt without shaking it for 1 day at 4°C in a refrigerator. After 1 day, yoghurt is ready to be consumed. Bon appetite.





STEAM CLEANING

This allows cleaning of the dirt that is softened by the steam occurred inside the oven without using chemicals.

Remove all accessories from the oven. Put 2 glasses of water inside the square tray, and place the tray to the bottom shelf.

Bring the thermostat to steam cleaning  mode. Set the timer to 30 minutes.

Bring the switch  to lower resistance mode. After operating the oven for 30 minutes, open the door and wipe the inner surface of oven with a damp cloth.




Digital clock usage

SUMMARY:

When the power is turned on for the first time, the timer's logo is displayed together with 00:00, and the time setting section flashes (the minutes section remains constant 00). The time can be set with the +, - buttons. Pressing the "M" button once, directs you to the minute setting section and the relevant section starts to flash (this time the hour section remains constant). Minutes setting can be done with the +, - buttons. Pressing the "M" button once again switches to automatic cooking mode. The automatic cooking logo and the time section flash (the automatic cooking minutes section remains constant). With the +, - buttons, cooking hour time can be adjusted. Pressing the "M" button once again shall cause the auto-cooking logo and minute section to flash.


With the +, - buttons, cooking time can be set in minutes. If the cooking time has been set, the remaining cooking time is displayed when the "M" button is pressed again. If the cooking time is not set, the current time is displayed if the "M" button is pressed again. If the "M" key is not pressed during the cases that require confirmation, the automatic confirmation is given within 20 seconds.

GENERAL OUTLOOK



WHEN THE POWER IS ON


When the power is on for the first time, the oven is off. The timer and the timer's logo are flashing on the screen. The time displayed on the screen is not correct and must be set (see Time setting).



TIME SETTING

Press 'M' button first and then you can adjust the time forward by pressing button + and backwards by pressing button -. Long press on these buttons will change the time faster.


Note: If the - or + key is not pressed for 20 seconds, the time setting mode ends automatically. You can terminate the time setting mode immediately by pressing the 'M' key.



AUTOMATIC COOKING PROGRAM


Cooking time must be set in order to cook in the oven.

Press "M" button to set cooking time mode. First, the hour section flashes and is set with the - or + button. Then press again the "M" button and the minutes setting part flashes and is set in the same way with the -or + key. If the button "M" is pressed again, or if no button is pressed for 20 seconds, the counter starts counting. An audible buzzer will notify when the time is over. The "M" button can be used to switch off the buzzer.



COMPLIANCE WITH AEEE REGULATIONS AND WASTE DISPOSAL

1- This product does not contain the dangerous and prohibited materials indicated in "Waste Electrical and Electronic Equipment Control Regulation" published by Ministry of Environment and Urbanisation of Republic of Turkey. Complies with AEEE Regulation.

- 2-  This product was manufactured from recyclable and reusable high quality parts and materials. Therefore, do not dispose of this product with other domestic wastes at the end of its life cycle. Take it to a collection point for electrical and electronic equipment. You can ask your local administration about these collection points.

You can help protect the environment and natural resources by delivering the used products for recycling. Before disposing of the product, cut the power cord and render it non-functional for children's safety.

PACKAGE INFORMATION

The product's packaging is made of recyclable materials, in accordance with the National Legislation. Do not dispose the packaging waste with the household waste or other wastes, dispose it to the packaging collection areas specified by local authorities.

Stimate client,

Vă mulțumim pentru că vă bazați pe produsele noastre. Scopul nostru este de a vă permite utilizarea optimă și eficientă a acestui produs prietenos cu mediul înconjurător fabricat în fabrici moderne sub condiții precise referitoare la sensul calității.

Înainte de utilizarea cuptorului, vă sfătuim să citiți acest manual de utilizare în întregime și să-l păstrați în permanență astfel încât caracteristicile cuptorului Simfer pe care l-ați achiziționat să rămână la fel ca în prima zi pe o durată lungă timp și să vă servească într-o modalitate eficientă și optimă.

RETINETI:

Acest manual de utilizare este pregătit pentru multiple modele. Produsul dumneavoastră poate să nu conțină unele funcții specificate în manual.

Imaginile produsului sunt schematic.

Acest produs a fost fabricat în fabrici moderne prietenoase cu mediul înconjurător fără a afecta natura.

"Este conform cu Reglementarea AEE".

CONȚINUT

Avertismente	17
Conexiune electrică și siguranță	20
Explicarea cuptorului și panoul de control	20
Specificații tehnice.....	21
Diagramă de gătire	22
Utilizarea cuptorului	22
Dacă cuptorul dumneavoastră nu funcționează.....	23
Lampă cuptor	23
Curățarea și întreținerea.....	23
Modul de utilizare a temporizatorului digital.....	24
Conformitate cu Reglementările AEEE și de eliminare a deșeurilor Informații despre ambalaj ..	26

(*) **opțiune**

AVERTISMENTE

Acest produs este fabricat conform reglementărilor de siguranță. Utilizarea neconformă a produsului poate cauza daune atât persoanei cât și a produsului.

Nu introduceți materiale inflamabile, sau materiale care se pot topi sau deforma datorită căldurii din interiorul cuptorului în ciuda posibilelor riscuri chiar și atunci când produsul nu este funcțional.

Produsul nu este proiectat pentru a fi setat din telecomandă sau pentru a fi controlat utilizând o telecomandă.

În momentul când produsul este funcțional, suprafața ușii poate atinge temperaturi înalte.

În timp ce suprafața produsului este încă fierbinte, nu turnați apă rece pe tavă sau în interiorul produsului. Suprafața produsul se poate avaria ca rezultat a schimbării imediate a temperaturii, iar acest lucru ducând la fierbere.

Utilizarea intensă pe termen lung a produsului poate necesita o ventilare suplimentară, de exemplu, deschiderea unei ferestre, sau o ventilare mai bună, cum ar fi creșterea nivelului de ventilare mecanică. Înainte de pornirea acestuia, îndepărtați perdelele, tulerile, hârtia sau orice material flamabil (ușor de aprins) departe de produs. Nu plasați materiale inflamabile în sau pe produs.

Fiți atenți la copii care se află în vecinătatea produsului.

Acest produs nu este destinat a fi utilizat de către persoanele cu dizabilități fizice, senzoriale sau mentale (inclusiv copii) sau de către persoanele care nu au o experiență corespunzătoare sau cunoștințe cu privire la utilizarea produsului, doar dacă aceștia sunt supravegheați de către o persoană responsabilă de siguranța produsului.

Produsul poate fi utilizat de către copii cu vârsta mai mare de 8 ani, persoanele cu abilități fizice, perceptivă sau mentale limitate sau persoanele cu lipsă de experiență și cunoștințe, dacă aceștia sunt supravegheați sau instruiți cu privire la funcționarea produsului și cu privire la oricare riscuri relevante care li se pot întâmpla.

Copii nu trebuie să se joace cu produsul.

Lucrările de curățare și întreținere ale produsului nu trebuie să fie efectuate de către copii nesupravegheați.

Produsul poate fi foarte fierbinte în timp ce este utilizat sau după un timp scurt după ce a fost utilizat; nu atingeți suprafețele arzătorului și nu permiteți copiilor să atingă aceste suprafețe.

Mențineți produsul și cablul de alimentare departe de copii sub vârsta de 8 ani. Copii vor fi supravegheați pentru a se asigura că nu se joacă cu produsul.

Acest produs este potrivit pentru a fi utilizat în casă și medii similare.

În momentul când ușa produsului este deschisă, nu aplicați presiune pe aceasta utilizând obiecte grele; nu vă sprijiniți, plasați obiecte grele pe ușă sau mânerul produsului.

Utilizați produsul pentru gătit și încălzirea alimentelor. Nu utilizați produsul în alte scopuri (încălzirea camerei, în scopuri comerciale etc.).

Înainte de înlocuirea lămpii și pentru prevenirea unui risc de șoc electric, asigurați-vă că produsul este deconectat.

ATENȚIE!

Suprafețele zonelor evidențiate prin această etichetă sunt fierbinți.
Nu atingeți.



Pentru modele cu buton declanșator, acest buton poate fi apăsat atunci când se află în poziția "0". Butonul poate fi setat prin rotirea spre stânga sau dreapta doar atunci când acesta este scos.

CONEXIUNE ELECTRICĂ ȘI SIGURANȚĂ

Produsul dumneavoastră necesită un curent de 13 amperi. Dacă este necesar, montajul trebuie efectuat de către persoane calificate.

Produsul dumneavoastră este proiectat pentru o alimentare de 220-240V, ~ 50/60Hz
Dacă specificațiile


tensiunii de alimentare sunt diferite față de valorile specificate, contactați persoanele calificate. Conexiunea electrică a produsului trebuie să fie efectuată doar prin intermediul prizelor cu împământare montate conform reglementărilor. Contactați service-ul autorizat dacă o priză cu împământare nu este disponibilă acolo unde produsul urmează a fi plasat.

Producătorul nu este responsabil pentru daunele cauzate de prizele fără împământare.

Dacă cablul de alimentare (ștecherul din cablu) este avariata, acest cablu trebuie să fie înlocuit de către importator sau de către agentul său de service sau de către un personal competent pentru a preveni o situație periculoasă.

Cablul de alimentare al produsului dumneavoastră nu va veni în contact cu componentele fierbinți ale produsului.

EXPLICAREA CUPTORULUI ȘI PANOUL DE CONTROL



1- Panou de control

2- Corp cuptor

3- Mâner

4- Plită

5- Arzătoare

6- Bazele cuptorului


7- Ușa din sticlă a cuptorului

8- Butoane de control


9- Tavă circulară (opțiune)

10- Tavă rectangulară

11- Grătar



Cronometru: Setează cronometrul la timpul de gătire recomandat și la gradul dorit. În momentul când timpul setat a expirat, cronometrul va deconecta alimentarea arzătoarelor și va furniza un avertisment cu un sunet. Pentru oprirea dispozitivului, setați butoanele cronometrului, programului

și termostatului în poziția zero. În momentul când cronometrul este setat la poziția , acesta va funcționa independent de oră.

Termostat: Termostatul asigură o temperatură de la 40 până la 240 °C în interiorul cuptorului.

SPECIFICAȚII TEHNICE

Caracteristici	CUPTOR MEDIU 45 LT
Lățime externă	590 mm
Adâncime externă	470 mm
Înălțime externă	330 mm
Lățime internă	440 mm
Adâncime internă	420 mm
Înălțime internă	240 mm
Termostat	40 până la 240 °C
Cronometru (*)	0 până la 90 min.
Arzător inferior	800 W
Arzător superior	600 W
Tensiune de alimentare	220-240V. ~ 50/60HZ.
Ventilator (*)	13- 15W
Lampă cuptor (*)	15W

(*): Această caracteristică este disponibilă doar pe anumite modele.

DIAGRAMĂ DE GĂTIRE

Mai jos, dumneavoastră puteți găsi informații despre alimentele pe care le-am testat în laboratoarele noastre pentru determinarea timpilor de gătire. Timpii de gătire pot varia datorită tensiunii de alimentare, calității, cantității alimentelor care urmează a fi gătite și temperaturii. Rețetele pe care le gătiți utilizând aceste valori nu se pot potrivi cu gustul dumneavoastră. Dumneavoastră puteți descoperi valori diferite prin efectuarea experimentelor pentru obținerea diferitelor miresme și rezultate care se potrivesc cu gustul dumneavoastră.

Aliment	Setarea termostat (°C)	Timp (min)	Ordine raft
Prăjituri	170-180	25-30	Raft central
Tort	170-190	30-40	Raft central
Plăcintă	180-220	40-50	Raft central
Brioșă	160-180	30-40	Raft central
Paste (coapte)	190-210	20-30	Raft central
Pește	220	30-40	Raft central
Miel	220	90-120	Raft central
Berbec	220	90-120	Raft central
Vițel	220-MAX	90-120	Raft central
Curcan	220-MAX	45-55	Raft central
Pasăre	220-MAX	75-100	Raft central
Decongelare	60-120	55-60	Raft central

*Înainte de gătire, preîncălziți cuptorul.

Puteți lua în considerare durata necesară până când lumina temperaturii este oprită pentru prima dată ca timp de pre-încălzire."

UTILIZAREA CUPTORULUI

Conectați ștecherul la o priză cu împământare. Aduceți cronometrul în poziția manuală sau automată de gătire. Setati termostatul la o temperatură corespunzătoare conform valorilor din diagrama de gătire. Dacă dumneavoastră ați setat cronometrul în poziția manuală, dumneavoastră veți auzi un sunet de avertizare la finalizarea gătirii.

În timpul primei funcționări a produsului, poate apărea fum și miros datorită întăririi materialelor de pe suprafața arzătorului. Acest lucru este normal și nu este un defect de fabricare.

Pentru gătitul iaurtului: Fierbeți laptele nepasteurizat. După ce laptele este răcit, acesta trebuie tratat. Setati temperatura cuptorului la 40 - 50 °C și utilizați ventilatorul. Gătiți laptele tratat în cuptor timp de 3 până la 3,5 ore într-o tigaie cu capac.

Decongelarea: Scoateți alimentele care urmează a fi decongelate din recipiente și apoi plasați-le pe grill. Glisați tava rectangulară sub grill pentru colectarea apei decongelate. În acest fel, alimentele decongelate nu vor fi lăsate în interiorul propriei ape. Nu utilizați apa decongelată (din motive de sănătate) și aruncați-o. Dumneavoastră puteți utiliza caracteristica de decongelare după cum este specificat în diagrama de gătire,

În timpul decongelării (☞) este recomandat să utilizați arzătoarele superioare și inferioare cât și ventilatorul turbo. Deoarece timpii de decongelare variază în funcție de greutatea alimentelor, verificați-le din când în când.

Nu gătiți utilizând tăvile rectangulare și circulare în același timp.

Înainte de gătire, noi recomandăm preîncălzirea cuptorului dumneavoastră 8 până la 10 minute.

Acest produs este destinat doar uzului casnic. Nu utilizați în alte scopuri.

DACĂ CUPTORUL NU FUNCȚIONEAZĂ

Vă rugăm să verificați dacă cablul de alimentare este conectat la priză în mod securizat.

Verificați tensiunea de alimentare a prizelor.

Verificați siguranța.

Verificați avariile cablului de alimentare. Contactați dealer-ul autorizat dacă problema nu este rezolvată.

LAMPĂ CUPTOR(*)



AVERTISMENT: Pentru evitarea șocului electric, asigurați-vă că circuitul dispozitivului este deschis înainte de înlocuirea lămpii. (Circuitul deschis înseamnă că alimentarea este deconectată.)

Deconectați mai întâi alimentarea produsului, și asigurați-vă că acesta este răcit.

Scoateți protecția sticlei prin rotirea acesteia după cum este prezentat în imagine.



Apoi, scoateți lampa prin rotirea acesteia, și montați noua lampă având aceleași specificații. Specificațiile lămpii vor fi după cum urmează:

230 V, AC

15W

Tip E14

La final, montați protecția sticlei în poziția sa originală.

ÎNȚREȚINEREA ȘI CURĂȚAREA

Deconectați produsul dumneavoastră.

Produsul poate fi foarte fierbinte în timp ce a fost utilizat sau după un timp scurt după ce a fost utilizat.

În acest caz, nu atingeți componentele fierbinți.


Nu curățați componentele interioare, panoul, tăvile și celelalte părți ale produsului cu instrumente dure cum ar fi perie aspră, burete de sârmă sau cuțit. Nu utilizați detergenți abrazivi.

Modul de utilizare a temporizatorului digital

REZUMAT:


Când alimentarea este pornită pentru prima dată, logo-ul temporizatorului este afișat împreună cu 00:00, iar secțiunea cu setarea de oră se aprinde intermitent (secțiunea pentru minute rămâne constantă la 00). Ora poate fi setată folosind butoanele +, -. Apăsând butonul „M” o dată, sunteți direcționați la secțiunea setării pentru minute și secțiunea relevantă începe să se aprindă intermitent (de această dată secțiunea pentru oră rămâne constantă). Setarea minutelor poate fi efectuată folosind butoanele +, -. Apăsarea încă o dată a butonului „M” va comuta la modul de gătit automat. Logoul pentru gătit automat și secțiunea pentru oră se aprind intermitent (secțiunea pentru minutele de gătit automat rămâne constantă). Folosind butoanele +, - setarea de oră pentru gătit poate fi reglată. Apăsarea încă o dată a butonului „M” va cauza din nou ca logoul pentru gătit automat și secțiunea pentru minute să se aprindă intermitent. Folosind butoanele +, -, timpul de gătit poate fi setat în minute. Dacă timpul de gătit a fost setat, timpul de gătit rămas este afișat atunci când se apasă din nou butonul „M”. Dacă timpul de gătit nu este setat, ora actuală este afișată dacă se apasă din nou butonul „M”. Dacă tasta „M” nu a fost apăsată în cazurile care necesită confirmare, după 20 de secunde se acordă o confirmare automată.

AȘTEPTĂRI GENERALE



CÂND ALIMENTAREA ESTE PORNITĂ


Când alimentarea este pornită pentru prima dată, cuptorul este oprit. Temporizatorul și logoul temporizatorului se aprind intermitent pe ecran. Ora afișată pe ecran nu este corectă și trebuie setată (consultați Setarea de timp).



SETAREA DE TIMP

Mai întâi apăsați butonul „M” și apoi puteți ajusta timpul înainte prin apăsarea butonului + și înapoi prin apăsarea butonului -. Apăsarea continuă a acestor butoane va schimba setarea de timp mai rapid.


Notă: Dacă tasta + sau - nu este apăsată timp de 20 de secunde, modul pentru setarea de timp se închide în mod automat. Puteți închide imediat modul pentru setarea de timp apăsând tasta „M”.



PROGRAMUL PENTRU GĂTIT AUTOMAT

Timpul de gătit trebuie setat pentru a găti folosind cuptorul.

Apăsați butonul „M” pentru a seta modul pentru timpul de gătit. Mai întâi, secțiunea pentru oră se aprinde intermitent și este setată cu butonul - sau +. Apoi apăsați din nou butonul „M” și partea cu setarea de minute se aprinde intermitent și este setată în același fel, folosind tastele - sau +. Dacă butonul „M” este apăsat din nou, sau dacă nu este apăsat niciun buton timp de 20 de secunde, temporizatorul se activează. Un semnal sonor va indica atunci când timpul a expirat. Butonul „M” poate fi utilizat pentru a opri semnalul sonor.



CONFORMITATE CU REGLEMENTĂRILE AEEE ȘI DE ELIMINARE A DEȘEURILOR

1- Acest produs nu conține materiale periculoase și interzise indicate în "Reglementarea de control a echipamentului electric și electronic" publicată de către Ministerul Mediului și Urbanizării al Republicii Turcia. Este conform cu Reglementarea AEEE.

2-



Acest produs a fost produs din materiale și componente reutilizabile de calitate înaltă și reciclabile. Așadar, nu eliminați acest produs împreună cu alte deșeuri menajere la finalizarea perioadei de funcționare. Transportați-l la punctul de colectare destinat pentru reciclarea echipamentului electric și electronic. Dumneavoastră vă puteți adresa administrației locale cu privire la aceste puncte de colectare.

Ajutați la protejarea mediului înconjurător și a resurselor naturale prin reciclarea produselor utilizate. Înainte de eliminarea produsului, tăiați cablul de alimentare și faceți-l să fie nefuncțional pentru siguranța copiilor.

INFORMAȚII DESPRE AMBALAJ

Ambalajul produsului este fabricat din materiale reciclabile, conform legislației naționale. Nu eliminați materialele de ambalare împreună cu gunoiul menajer sau alte deșeuri, eliminați-l în zone de colectare a materialului de ambalare specificat de către autoritățile locale.

